

Instructions for Unibar® Part #14914

Fits Honda Rebel CMX 250cc 1995-Present



www.lindbycustom.com
320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove the lower 8mm bolt in the front motor mount.
2. Install the lower brackets of the UNIBAR to the motor mount where you removed the 8mm bolt. Install the longer 8mm bolt there that was supplied in the hardware kit. Do not Tighten yet.
3. Hold the top bracket of the UNIBAR up to the down tube of the frame and install the supplied U Bolt and the half moon part. Then install the 2 spacers on the U Bolt followed by the top bracket of the UNIBAR. Lastly install the 8mm washers and nuts.
4. Tighten all the nuts and bolts.

***Hardware Included:**

- 1 U bolt 5/15 x 1 1/8"
- 1 8mm x 80mm hex bolt
- 2 8mm flat washers
- 1 8mm nylon nut
- 2 Spacers 8mm x 3/16" thick

