

Instructions for Linbar®

Part # 704-1, 13704, 14704

Fits Victory Cross Country & Crossroads 2010- up

**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Install the Top right highway bar using short 10mm x 30mm hex bolt to the mounting point just in front of the fuel tank
2. Install the lower mount using the longer 10mm x 60mm hex head bolt and the spacer to the mounting point in front of the front floor board mount.
3. Repeat the process on the left side.
4. Tighten all bolts to the manufacturer specifications (28 foot pounds)
5. Hardware included:
 - 2 Hex bolts 10mm x 60mm x 1.50
 - 2 Hex bolts 10mm x 30mm x 1.50
 - 2 Spacers 1 1/2

