

Instructions for Part # 111-5

For use with part #111-1, 1986-1999

Softail models

**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove left and right forward control.
2. Install right bracket (the bracket with 3 holes) between the frame and the right forward control using the longer bolts.
3. Install left bracket (the bracket with 8 holes) between the frame and the left forward control using the longer bolts.
4. Install the top bolt 5/16" X 1" through the top mount between the 2 down tubes into the LINBAR's top mount (do not tighten yet).
5. Install the left and right lower mount of the LINBAR to the bracket kit you just installed using 3/8" X 16 X 1 1/4" bolts and nylon lock nuts.
6. Tighten all bolts to factory spec.