

Instructions for Twinbar® Part # 1202/09, 1203/09

1202/09 Fits Dresser and Roadking Models 1997-2013

1203/09 Fits Roadglide 1998-2013

**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove OEM engine guard.
2. Install top mount so the top bracket fits inside the frame (the nut is adjustable in the bracket). After you mount the top bolt through the frame into the adjustable nut, be sure you can move the bar up and down for easier installation of the two lower mounting bolts.

Install the 5/16" allen bolt through the frame and then into the Twinbar, install the 2 lower mounts using the 2 3/8" x 16 x 1 1/4" bolts and nylon lock nuts.

3. **Important: Make sure the bolts holding the flip down pegs are tight.**
4. Tighten all bolts to manufacturer's specifications.

