

Instructions for Linbar[®], Multibar[®] and Unibar[®] Part # 605-1, 13605, 14605

Fits Yamaha Roadliner and Stratoliner 2006-up



www.lindbycustom.com
320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove left and right floorboard, install the left and right lower mount of the highway bar at the front mounting bolts of the floorboard mount (between the frame and the floorboard bracket) use the 1/4" spacer at the rear bolt (between the frame and the floorboard bracket). Do not tighten yet.
2. Hold the top of the Linbar / Multibar against the top of the frame, install the claw like brackets between the frame and the highway bar so the brackets grab around the left and right down tube of the frame. Install the 2 8mm bolts through the highway bar into the threaded brackets.
3. Tighten all bolts to manufacturer's specifications

Hardware Included*

- 2 spacers 1/4" x 7/8" o.d.
- 2 aluminum claw brackets
- 2 Flange hex bolts 8mm x15mm x 1.25

