

# Instructions for Combined Engine Guard and Highway Peg Linbar® Part # 701-1

Fits Victory Polaris from 1999-2001

**LINDBY  
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove 2 upper allen bolts in top engine-mount and install bracket. Tighten bolts to manufacturer's specifications.
2. Remove front left and right bolts in floorboard.
3. Install the topmount of the engine guard with 3/8" x 1 1/4" bolt, do not tighten yet.
4. Install the two lower bolts you removed before and tighten all bolts to manufacturer's specifications.
5. Hardware included:
  - 1 Hex bolt 3/8 x 16 x 1 1/4
  - 1 Nylon lock nut 3/8 x 16
  - 2 Sae flat washers
  - 1 Top bracket

\*Bar width: 32 1/4"

