

Instructions for Combined Engine Guard and Highway Peg Linbar® Part # 702-1

Fits Victory Kingpin and Vegas 2003-2005

**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Replace L&R front bolt in floor board bracket with the supplied bolts. Only tighten bolts so they are even with the inside of the frame.
2. Remove the bolt at the top motor mount.
3. Install the two lower mounts of the Linbar where you replaced the two bolts, hold the linbar and tighten the L&R bolts so they come through the brackets of the Linbar. Install the two washers and nylon lock nuts, do not tighten yet.
4. Align the top of the Linbar with the hole in the upper motor mount and install the treadet rod and the spacers between the frame and the Linbar.
5. Tighten all bolts to manufacturer's specifications.
6. Hardware included:
 - 1 Tredet rod 7/16-14...Cut 12 $\frac{1}{2}$
 - 2 Nylon lock nuts 7/16-14
 - 2 Sae flat washers 7/16
 - 2 Spacers 1" x 4"
 - 2 Allen bolts 10-1.50 x 70
 - 2 Nylon lock nuts 10-1.50
 - 2 Washers 3/8

