

Instructions for Linbar[®], Multibar[®] and Unibar[®] Part # 801-1, 13801, 14801

Fits Suzuki Intruder 1500CC

LINDBY
CUSTOM, INC
metric

www.lindbycustom.com
320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove rubber plugs in frame just above front cyl. head.
2. Remove the front bolts from l/r floorboard mounts.
3. Install spacers on frame and install the highway bar with long threaded rod and acorn nuts.
4. Install lower bolts in l/r floorboard.
5. Tighten all bolts to manufacturer's specifications.
6. Hardware included:
 - 1 Tredet rod 3/8 x 16 x 11 1/4
 - 2 Nylon lock nuts 3/8 x 16
 - 2 Sae flat washers 3/8
 - 2 Machined spacers 2"

