

# Instructions for Linbar® and Multibar® Part # 901-1, 13901

Fits Kawasaki 1500 cc



www.lindbycustom.com  
320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove front bolt in left and right side floorboard mount.
2. Underneath lower tripletree is an oval hole, remove 2 bolts that hold the horn.
3. Install highway bar using 2 long bolts and washers and the 2 spacers (1 3/4" long). The spacers will fit in the oval shaped hole in the frame, the cable fits in the machined slot in the top bracket.
4. Install left and right side bolts you removed in no. 1.
5. Tighten all bolts to manufacturer's specifications.
6. Hardware included:
  - 2 Hex bolts 6mm x 70 x 1.0
  - 2 Flat washers 6mm
  - 2 Sae flat washers 6mm
  - 2 Spacers 5/8 x 5/8 x 50mm

\*Bar width: 34"

