

Instructions for Linbar[®] and Multibar[®] Part # 902-1, 13902

Fits Kawasaki 1600 cc



www.lindbycustom.com
320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove front bolts in left and right side floorboard mount.
2. Remove the top bolt for the radiator.
3. Install Linbar or Multibar using the longer 6mm bolt and washers provided. The spacer goes between the Linbar/Multibar and the top mount of the radiator.
4. Install the right lower bolt through the Linbar/Multibar bar and into the frame and now install the left side bolt using the provided spacer between the Linbar/Multibar and the frame.
5. Tighten all bolts to manufacturer's specifications.
6. Hardware included:
 - 1 Hex bolt 6mm x 40mm x 1.0
 - 1 Flat washer 6mm
 - 1 Fender washer 6mm
 - 2 Spacer 3/8

*Bar width: 36 $\frac{1}{4}$ "

