

# Instructions for Linbar<sup>®</sup>, Multibar<sup>®</sup> and Unibar<sup>®</sup> Part # 905-1, 13905, 14905

Fits Honda VTX 1800 Classic and F 2001-up  
Does not fit on Retro models



www.lindbycustom.com  
320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove the 3 bolts that holds on the radiator to the frame and loosen the upper radiator hose clamp and rotate a 180 deg. and tighten again (make sure the engine is cold and that there is no pressure in the system).
2. Remove the 2 lower bolts on left and right forward controls.
3. Install the top mount of the highway bar between the frame and the radiator and install the 6mm bolt. Do not tighten. Also install the 2 lower bolts for the radiator.
4. Install the 2 lower bolts through the highway bar and into the frame on the forward controls and tighten all bolts to the manufacturer's specifications.

\*Bar width: 35"

