

# Instructions for Linbar<sup>®</sup> and Multibar<sup>®</sup> Part # 912-1, 13912

Fits Honda Shadow Spirit 750 cc 2000-up  
Will not fit Spirit 750 cc C2 w/shaft drive 2007-up,  
use part #910-1



www.lindbycustom.com  
320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove the top bolt holding the radiator.
2. Install the 2 brackets between the frame and the forward controls. Do not tighten bolts yet.
3. Loosen the two lower mounts.
4. Take the bolt out of the horn mount and flip the horn to the backside of the bracket — if you don't do that the horn will rub against the LINBAR / MULTIBAR.
5. Install the LINBAR / MULTIBAR between the frame and the radiator using the existing 6mm bolt. Do not tighten yet.
6. Install left and right lower mount of LINBAR / MULTIBAR to the bracket you installed in step 2 using the supplied nuts and bolts.
7. Make sure that the rear brake is adjusted correctly, so the brake pedal doesn't touch the LINBAR / MULTIBAR when applied.
8. Adjustment of the gear lever may be necessary.
9. Tighten all bolts to manufacturer's specifications.
10. Hardware included:
  - 2 Brackets
  - 2 Hex bolts 3/8 x 16 x 1 1/4"
  - 2 Nylon lock nuts 3/8 x 16
  - 4 Sae flat washers 3/8