

Instructions for Linbar[®], Multibar[®] and Unibar[®] Part # 913-1, 13913, 14913

Fits Honda VT1300 Sabre, Interstate
and Stateline, 2010-up



www.lindbycustom.com
320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Install the 1/4" spacer on the upper support bolt for the floorboard/forward controls on left and right side of the motorcycle.
2. Install the left and right side of the highway bar on the lower support bolt for the floorboard/forward control, then install the lower brackets between the frame and the spacer.
3. Install the two black claw brackets between the down tubes of the frame and secure with the two 8mm bolts supplied in the hardware kit. Make sure that the rubber strip is installed on the claw bracket before installing.
4. Tighten all bolts to the manufacturer's specifications.

* Hardware Included:

- 2 Flange Hex Head bolts 8mm x 20mm x1.25 pitch
- 2 spacers 1/4" x 7/8" O.D.
- 2 Claw Brackets
- 2 Flat rubber strips

