

Instructions for Linbar[®], Multibar[®] and Unibar[®] Part #115-1, 1315, 1415

Fits Sportster Rubber Mount Engine 2004-up

**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove two bolts in upper front engine stabilizer.
2. Install supplied brackets between the forward controls and the frame on left and right side.

NOTE: *On motorcycles with mid controls install the brackets on the 2 mounting points where the forward controls mount. Use the 3/8" x 1" bolts supplied.*

3. Install the top mount of the highway bar using the 2 bolts you uninstalled in step 1.
4. Install the 2 lower mounts of the highway bar to the brackets you installed in step 2, using provided nuts, bolts and washers.
5. Tighten all bolts to factory spec.
6. Hardware included:
 - 2 Hex bolt 3/8 x 16 x 1 1/4
 - 2 Hex bolt 3/8 x 16 x 1 1/2
 - 4 Hex bolt 3/8 x 16 x 1
 - 2 Nylon lock nuts 3/8 x 16
 - 10 Sae flat washers 3/8
 - 2 **Brackets with Slot**

*Bar width: 31"

NOTE: *If there is not enough clearance between front exhaust and the highway bar, adjustment of exhaust system may be needed.*

