

Instructions for Twinbar®

Part # 1202, 1203

1202 Fits Dresser and Roadking Models 1997-2008
1203/15 Fits Roadglide 1998-2019 (except 19' cvo model)

**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove OEM engine guard.
2. Install top mount so the top bracket fits inside the frame, install the 5/16" allen bolt through the frame and then into the Twinbar, install the 2 lower mounts using the 2 3/8" x 16 x 1 1/4" bolts and nylon lock nuts.
3. **Important: Make sure the bolts holding the flip down pegs are tight.**
4. Tighten all bolts to manufacturer's specifications.

