

# Instructions for Linbar<sup>®</sup>, Multibar<sup>®</sup> Unibar, and Magnumbar Part # 102-1/09, 1302/09, 1403 & 1702

Fits Dresser, Road King 1997 to present

**LINDBY  
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove OEM engine guard.
2. Install top mount so the top bracket fits inside the frame (the nut is adjustable in the bracket). After you mount the top bolt through the frame into the adjustable nut, be sure you can move the bar up and down for easier installation of the two lower mounting bolts.
3. Install the 5/16" allen bolt through the frame and then into the highway bar.
4. Install the 2 lower mounts using the bolts you took out in step one or use the two 3/8" x 16 x 1 1/4" bolts supplied in the hardware kit.
5. Tighten all bolts to factory specifications.
6. Hardware included:
  - 1 Allen bolt 5/16 x 18 x 1
  - 2 Hex bolts 3/8 x 16x 1 1/4
  - 2 Nylon lock nut 3/8 x 16
  - 1 Sae flat washer 5/16
  - 4 Sae flat washers 3/8

