

Instructions for Front Linbar® Part # 112-1

Fits Sportster 1986-up
(with stock Harley-Davidson forward controls)

**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove two bolts in front upper motormount.
2. Install top mount of the Linbar where you removed two upper bolts.
3. Install bolt, washers and nut, with the short spacer placed between the Linbar and the forward control, on left side in exiting hole in lower front forward control bracket.
4. Install bolt, washers, nut and long spacer in exiting hole on right lower front forward control bracket.
5. Tighten all bolts to factory spec.
6. Hardware included:
 - 2 Hex bolts 3/8 x 16 1 1/2
 - 1 Hex bolt 3/8 x 16 x 2
 - 1 Hex bolt 3/8 x 16 x 2 1/2
 - 2 Nylon lock nuts 3/8 x 16
 - 6 Sae flat washers 3/8
 - 1 Spacer 1/2"
 - 1 Spacer 1 1/2"

*Bar width: 30 1/2"

NOTE A: If there is not enough clearance between front exhaust and the Linbar, adjustment of exhaust system may be needed.

NOTE B: Adjustment of the gear lever may be necessary to give the correct clearance between the Linbar and the gear lever.

