

# Instructions for Linbar<sup>®</sup>, Multibar<sup>®</sup> and Unibar<sup>®</sup> Part # 604-1, 13604 and 14604

Fits Yamaha V-Star Classic & Custom  
1100 cc 1998-up

**LINDBY**  
**CUSTOM, INC**  
*metric*

www.lindbycustom.com  
320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove left and right floorboards and install flat stock brackets between frame and bracket for the floorboards. Do not tighten bolts yet.
2. Remove two 6mm bolts placed under lower triple three and install the highway bar reusing the two 6mm bolts. Do not tighten yet.
3. Connect the lower mounts of the highway bar to the previously installed flat stock brackets.
4. Lift up highway bar and make sure that it is level and tighten down all the bolts to the manufacturer's specifications.
5. Turn handlebars to the left and right to make sure that the brake line is clear between fork and highway bar, adjust guides if necessary.
6. Hardware included:
  - 2 Hex bolts 3/8 x 16 x 1 1/4
  - 2 Nylon lock nuts 3/8 x 16
  - 4 Sae flat washers 3/8
  - 2 Flat stock brackets 6"
  - \* Bar Width: 33 7/8"

