

# Instructions for Linbar<sup>®</sup>, Multibar<sup>®</sup> and Unibar<sup>®</sup> Part # 608-1, 13608, 14608

Fits Yamaha Raider 2008-Present



www.lindbycustom.com  
320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove the horn from the forward control bracket.
2. Remove left and right forward controls, install the left and right lower mount of the highway bar at the front mounting bolts of the forward controls (between the frame and the forward controls), using the 1/4" spacer at the rear bolt (between the frame and the forward control bracket). Do not tighten yet.
3. Hold the top of the Linbar / Multibar / Unibar against the top of the frame. Install the Flat Stock Bracket on the opposite of the Frame and install the 2 spacers on the 5/16 x 2 1/2 Bolts. Then Secure with the Nylon Lock Nuts.
4. Install the horn using the black relocater plate with the four holes.
5. Tighten all bolts to manufacturer's specifications.

**\*Hardware Included:**

- 2 Spacers 1/4" x 7/8 O.D.
- 2 Aluminum Claw Brackets
- 2 Flange Hex Head bolts 8mm x 15mm x 1.25
- 2 Flange Hex Head bolts 6mm x 30mm x 1.0
- 2 Nylon lock nuts 6mm
- 1 Plate 1 3/4" x 1 3/4" with 4 holes

