

Instructions for Combined Engine Guard and Highway Peg Linbar[®] and Multibar[®]

Part # 703-1, 13703, BL13703

Fits Victory Kingpin, Vegas and Jackpot 2006-present

**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Replace left and right front bolt in floor board/ foot peg mount bracket with the supplied 10mm. allen bolts.
2. Install the left and right side highway bar's lower mounts where you replaced the two bolts, hold the highway bar, install the two washers and nylon lock nuts, do not tighten yet.
3. Align the top of the highway bar with the down tubes at the left and right side of the frame and install the U-shaped aluminum brackets around the down tubes with the supplied 8mm bolt's (it may be necessary to loosen up the 2 nuts at the front header pipe to get enough clearance to install the clamp).
4. Install the last part of the highway bar between the two lower mounts of the highway bar with the supplied nuts and bolts.
5. Tighten all bolts to manufacturer's specifications.



Hardware Included:

- 2 Allen Bolts 10mm x 70mm 1.50 pitch
- 2 Nylon Lock Nuts 10mm 1.50 pitch
- 2 Flat Washers 10mm
- 2 Flange Hex Head Bolts 8mm x 25mm x 1.25
- 4 Flange Hex Head Bolts 8mm x 20mm x 1.25
- 4 Flat Washers 8mm
- 2 Nylon Lock Nuts 8mm x 1.25
- U shaped Brackets

Note: The Highwaybar comes in 3 Pieces (Left,Right,Center)