Instructions for Linbar® and Multibar® Part #802-1, 13802 and 14802

Fits Suzuki Volusia 800cc 200-up



www.lindbycustom.com 320 E. Crowther Ave., Placentia, CA 92870 Phone (714) 528-0085 • Fax (714) 528-0087

- 1. Remove rubber plugs in L & R down tubes.
- 2. Remove the front bolts from L & R floorboard mounts.
- 3. Install the L & R lower mounts of the Linbar using the 2 bolts you removed from the L & R floorboards.
- 4. Install the L & R upper mounts using the provided bolts and spacers, install the bolts where you removed the rubber plugs.
- 5. Tighten all bolts to manufacturer's specifications.
- 6. Hardware included:
 - -(2) 10mm x 40mm 1.25 Tread
 - -(2) 10mm flat washers
 - -(2) Spacers 5/8" Long

*Bar width: 36"

