

# Instructions for Linbar<sup>®</sup>, Multibar<sup>®</sup> and Unibar<sup>®</sup> Part # 907-1, 13907 and 14907

Fits Honda VTX 1300 Retro 2002-up  
and Honda VTX 1300 C 2004-up

**LINDBY**  
**CUSTOM, INC**  
*metric*

www.lindbycustom.com  
320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove the horn: Uninstall the 2 6m/m bolts at the top of the radiator and the front bolt in the L and R floorboard mount (on the C model the foot peg mount).
2. Install the highway bar using the 2 longer supplied 6m/m bolts and place the 2 long spacers between the highway bar and the radiator and the cover plate. Do not tighten the bolts yet.
3. Install the L and R bolt through the highway bar and the front floorboard mount (on the C model the foot peg mount). Tighten the bolts to the manufacturer's specs.
4. Install the horn using the short spacer and the longer 8-m/m bolts. On the C model mount the horn on the upper left radiator bolt.
5. Hardware included:
  - 2 Hex bolts 6mm x 55 x 1.0
  - 1 Hex bolt 8mm x 20 x 1.0
  - 2 Flat washer 8mm
  - 1 Flat washer 8mm
  - 1 Spacer 1/4"
  - 2 Spacers 5/8"

\*Bar width: 36<sup>1</sup>/<sub>4</sub>"

