

Instructions for Linbar® Part # 908-1, 13908, 14908

Fits Honda Shadow 1100 Saber/Spirit



www.lindbycustom.com
320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove bolt holding the radiator
2. Remove L/R lower bolts in the forward controls.
3. Move radiator out and down and install the LINBAR between the frame and the radiator using the longer 6mm bolt provided.
4. Install L/R lower mount of the LINBAR using the bolts you removed in step 2.
5. Tighten all bolts to manufacturer's specifications.
6. Check clearance for brake line and turn signal, adjustment of brake line clip and L/R turn signal lamp may be necessary.
7. Hardware included:
 - 1 Hex bolts 6mm x 40mm x 1.0
 - 1 Flat washers 6mm
 - 1 Fender washers 6mm

*Bar width: 35"

