

Instructions for Linbar[®], Multibar[®] and Unibar[®] Part # 910-1, 13910, 14910

Fits Honda Shadow Aero 750 cc 2004-up
and Honda Spirit 750 cc C2 w/Shaft Drive 2007-up



www.lindbycustom.com
320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove the top bolt holding the radiator.
2. Remove left and right front bolt in foot control brackets.
3. Install LINBAR/ MULTIBAR to the frame at the top radiator mount. Use the longer 6mm bolt provided in bolt kit.
4. Install left and right lower mount of LINBAR/ MULTIBAR to the lower foot peg mount.
5. Make sure that the rear brake is adjusted correctly, so the brake pedal doesn't touch the LINBAR/ MULTIBAR when applied.
6. Tighten all bolts to manufacturer's specifications.
7. Hardware Included:
 - 1 Hex bolt 6mm x 35mm x 1.00 (10.9)
 - 1 Flat washer 6mm
 - 1 Fender washer 6mm

*with thick brackets:

 - 1 Hex bolt 10mm x 40mm x 1.25
 - 1 Hex bolt 10mm x 100mm x 1.25
 - (2) 10mm flat washer

*Bar width: 36¹/₄"

